




www.polymak.co.in

SPARE PARTS LIST

No	Parts Name	Pcs	Seri No	INR	No	Parts Name	Pcs	Seri No	INR
1	Insulation sleeve	1			38	Bearing 6200	1		
2	screw M5×25 (triple combination)	1			39	Bearing press plate	5		
3	Gear box cover	1			40	Screw M5×12	3		
4	Blade screw	1			41	Armature	1		
5	Blade clamping sleeve	2			42	Bearing 608	1		
6	Blade Hex nut screw	1			43	Windshield	1		
7	Sealing gasket frame	1			44	Handle cover (right)	1		
8	O-rings 16 x 2.2	1			45	Switch	2		
9	Sealinggasket	1			46	Cable press plate	1		
10	Square bearing	1			47	Cable protector	1		
11	Press plate II	1			48	Cable	1		
12	Screw M5×14	1			49	Saw blade guide plate	1		
13	Reciprocating rod assembly	1			50	Washer 5×13×1	1		
14	Needle bearing Nk071408	1			51	Hex nut screw M5×12	1		
15	Pin 7 x 19	1			52	Saw blade	1		
16	Screw M5×16	1			53	Hex nut spanner	1		
17	Gasket II	1							
18	Big gear	1							
19	Gasket I	1							
20	Needle bearing Hk121816	1							
21	Gear box	1							
22	Screw S14×55	1							
23	Screw M5×14	1							
24	Filed Coil	1							
25	Tension spring	1							
26	Housing	1							
27	Brush holder	1							
28	Carbon brush	1							
29	Brush holder cover	1							
30	Screw S14×14	1							
31	Handle cover (left)	1							
32	Wool felt	1							
33	Press plate I	2							
34	Intermediate shaft	1							
35	Screw S15×25	2							
36	Rubber column 4 x 9	2							
37	Shaft ring	2							