



# 9718EI Polisher

## Spares List

Position No	Part No	Description
1	341006	Wool wheel
2	310134	Polishing disc
3	133080	Spindle
4	276002	Key
5	115003	Dust Protector
6	231027	Screw
7	241002	Spring Washer
8	161018E	Flange
9	211067	Bearing
10	243005	Wave Washer
11	251005	Retainer Ring
12	137005	Big Gear
13	252004	Retainer Ring
14	212009	Needle Bearing
15	145006	Self-locking Pin
16	231152	Screw Assy.
17	231027	Screw
18	241002	Spring Washer
19	151001	Spring
20	317005	Self-locking Button
21	221026	Tapping Screw
22	162033	Gearbox
23	252004	Retainer Ring
24	211043	Bearing
25	116008	Bearing Clamp
26	442027	Armature
27	319034	Plastic Ring
28	211020	Bearing
29	321011	Wind Deflector
30	232012	Socket Head Cap Screw
31	242007	Washer
32	627027	Auxiliary Handle
33	221044	Tapping Screw
34	441028	Coil
35	433002A	Brush Cap
36	431007B	Carbon Brush Assy.
37	432001A	Brush Holder
38	313216	Motor Shell
39	314083	Left Handle
40	221010	Tapping Screw

Position No	Part No	Description
41	445007	Switch
42	447026	Speed Controller
43	272001	Rivet
44	151023	Switch Spring
45	443008	Capacitor
46	314084	Right Handle
47	222002	Tapping Screw
48	318001	Cable Clamp
49	332006	Cable Sleeve
50	411028	Power Cord
51	622002	Hex Spanner
52	331012	Bearing Sleeve
201	712044	Handle Assy.